3-IN-1 POKER TABLE ASSEMBLY INSTRUCTIONS



Please Do Not Hesitate to
Contact Our Consumer Hotline
at 800-759-0977
with Any Questions That May
Arise During Assembly or
Use of This Product!

THANK YOU!

Thank you for purchasing this product.

We work around the clock and around the globe to ensure that our products maintain the highest possible quality. However, in the rare case of issues during assembly or use of this product, please contact our Consumer Hotline at **800-759-0977** for immediate assistance before contacting your retailer.

Please read the warranty information at the back of these assembly instructions for further details.

IMPORTANT! PLEASE READ THESE ASSEMBLY INSTRUCTIONS IN ENTIRETY BEFORE ASSEMBLING YOUR PRODUCT.


PARTS IDENTIFIER (NOT TO SCALE)

TABLE


#1	#2	#3	#4	#5
TABLE BODY 1 pc	LEG 4 pcs	PEDESTAL 1 pc	PLATE 1 pc	TABLE TOP 1 pc
#6	#7	#8	#9	#10
				®
TABLE PROTECTOR	BOLT	FLAT WASHER	WRENCH	NUT
8 pcs	6 pcs	18 pcs	1 pc	12 pcs
#11	#12	#13	#14	#15
1				
LEG LEVELER	BUMPER POOL BALLS	BUMPER POOL CUE STICK	CHALK	BRUSH
4 pcs	1 SET	2 pcs	2 pcs	1 pc

PARTS IDENTIFIER (NOT TO SCALE)

CHAIR



CHAIR HARDWARE



ASSEMBLY TIPS

- 1. Find a clean, level surface to begin the assembly of your game table. We recommend that two adults work together to assemble this game. You may want to carefully cut or tear the four corners of the box so that the bottom of the box can be used as your work surface.
- 2. Remove all of the contents from box and verify that you have all of the parts shown on the Parts Identifier before you begin assembly. **Note: Some parts may be pre-installed or pre-assembled.**
- 3. Some figures or drawings may not look exactly like your product. Please read and understand the text before beginning each assembly step.
- 4. When installing parts that have more than one screw or bolt, hand tighten all screws or bolts in place before final tightening with screwdriver or wrench.
- 5. Electric screwdrivers may be helpful during assembly; however, please set a *low torque* and use extreme caution because screws may be stripped or overtightened, resulting in damaged parts, if the electric screwdriver's torque is set too high.

WARNINGS!


READ AND FOLLOW ALL ASSEMBLY, OPERATION AND SAFETY INSTRUCTIONS CAREFULLY.

CHOKE HAZARD - THIS TABLE CONTAINS SMALL BALLS AND PARTS NOT SUITABLE FOR CHILDREN UNDER 3 YEARS OF AGE.


ASSEMBLY INSTRUCTIONS

TABLE


1. Attach PLATE #4 to PEDESTAL #3 with NUT #10 and FLAT WASHER #8.



- 2. Attach assembled PEDESTAL to the bottom of the TABLE BODY #1 with BOLT #7 and FLAT WASHER #8.
- 3. Attach LEGS #2 to PEDESTAL with NUT #10 and FLAT WASHER #8. Thread one LEG LEVELER #11 onto each LEG.




4. Carefully turn table over. Place TABLE TOP #5 on top of assembled TABLE.



ASSEMBLY INSTRUCTIONS

CHAIRS



CONGRATULATIONS!

You have now assembled your Game Table. Please note the Care and Use instructions below to ensure years of trouble free use of your game table.

CARE AND USE

- 1. This product is intended for **INDOOR** use only.
- 2. Do **NOT** sit, climb or lean on the table.
- 3. Do **NOT** drag the table when moving it as this will damage the legs.

1-YEAR LIMITED WARRANTY

This product is warranted to the original purchaser to be free from defects in material or workmanship for a period of one year from the date of the original retail purchase.

This warranty does not cover defects or damage due to improper installation, alteration, accident or any other event beyond the control of the manufacturer. Defects or damage resulting from misuse, abuse or negligence will void this warranty. This warranty does not cover scratching or damage that may result from normal usage.

This product is not intended for institutional or commercial use; the manufacturer does not assume any liability for such use. Institutional or commercial use will void this warranty.

This warranty is nontransferable and is expressly limited to the repair or replacement of the defective product. During the warranty period, the manufacturer shall repair or replace defective parts at no cost to the purchaser. Shipping charges and insurance are not covered and are the responsibility of the purchaser. Labor charges and related expenses for removal, installation or replacement of the product or components are not covered under this warranty.

The manufacturer reserves the right to make substitutions to warranty claims if parts are unavailable or obsolete.


The manufacturer shall not be liable for loss of use of the product or other consequential or incidental costs, expenses or damages incurred by the consumer of any other use. The user assumes all risk of injury resulting from the use of this product.

This warranty is expressly in lieu of all other warranties, expressed or implied, including warranties of merchantability or fitness for use to the extent permitted by Federal or state law. Neither the manufacturer nor any of its representatives assumes any other liability in connection with this product.


All warranty claims must be made through the retailer where the product was originally purchased. A purchase receipt or other proof of date of purchase will be required to process all warranty claims. The model number and part numbers found within the assembly instructions will be required when submitting any parts requests or warranty claims.

For further warranty information or inquiries, please call 800-759-0977

3-IN-1 DARK OAK POKER TABLE - NG2351T Parts List




PARTS




*HARDWARE PACK - NGP2331 includes parts 6, 7, 8, 9 & 10

3-IN-1 DARK OAK CHAIRS - NG2351C Parts List




^{*} Parts 22 and 23 are available as a set


HARDWARE PACK - NGP2345 (includes ALL parts below)



3-IN-1 WALNUT POKER TABLE - NG2366T Parts List




PARTS



*HARDWARE PACK - NGP2331 includes parts 6, 7, 8, 9 & 10

3-IN-1 WALNUT CHAIRS - NG2366C Parts List



^{*} Parts 22 and 23 are available as a set

HARDWARE PACK - NGP2345 (includes ALL parts below)

A x4	В х8	C x2	D1 x8	E x4	F x8	G x4
0	0	— ®	0	— ®	— (9	— ®
1/4" FLAT WASHER	5/16" FLAT WASHER	BOLT 1/4" x 1-1/2"	5/16" LOCK WASHER	BOLT 1/4" x 2"	BOLT 5/16" x 2-1/2"	BOLT 1/4" x 1-1/4"
H x3	l x1	J x1				
\ @	EG					
#8 SCREW x 1-1/2"	WRENCH	HEX WRENCH				