




## Quick Reference Guide

# OmniLogic®

## Wired Network Setup



### 1. Connect MSP to Home Router



### 2. Configure wired connection by selecting:

Config>Wired Networking>

For dynamic (DHCP):

- select "dynamic" on text bar
- confirm and save with check mark

**Note: Network status (top left) should be in "ON" position**



For static (Fixed IP):

- select "static" on text bar
- enter IP for each field
- confirm and save with check mark


**Note: Network status (top left) should be in "ON" position**



# Quick Reference Guide - Wi-Fi Bridge Setup

## HLWLAN Network Setup

### 1. Connect HLWLAN hardware to OmniLogic



### 2. Configure Wi-Fi bridge by selecting Config>wifi bridge>

- A. Select the desired network name (SSID) from the list that appears, then enter the network password

**Note: Passwords ARE case sensitive and may be supplied by the router**



- B. Verify IP addresses are present after connecting to Wi-Fi. If no IPs, check information and repeat Step A

**Note: May take several minutes to connect once credentials are accepted**



If no IP address is issued:

- Check connection and signal strength using another Wi-Fi ready device
- Verify network encryption through router

To view OmniLogic tutorials please visit: [www.hayward.com/omnivideos](http://www.hayward.com/omnivideos)

To take a closer look or see other Hayward products please go to:

[www.hayward.com](http://www.hayward.com) or call 1-844-365-6442